




# **COMPUTER VISION**

Final Project: Gaze Detection

Giovanni Gallinaro


ID: 1210127



## Organization



- Faces and eyes features detection
- Pre processing phase
- Iris and sclera corners detection
- Gaze direction recognition




## Faces and Eyes Recognition



Firstly we extract the relevant features in the image and we organize them in an

efficient way:

- Use Haar Feature-based Cascade Classifiers
- Organize eyes in 2D array (multiple faces)
- Crop the image








# Pre-processing



- Convert to gray-scale
- Enhance contrast
- Select threshold for binary segmentation





# Threshold computation



Darker images require a higher threshold in order to obtain a good binary segmentation, so we proceed as follows:

- Compute the histogram
- Compute a weighted average of the histogram values of the image where the weight is the intensity
- Quantize the output value







#### Iris detection



- Select multiple thresholds around the optimal one (Watershed Multiple Thresholding)
- Apply binary segmentation
- For each threshold compute the barycenter of the black cluster
- Compute the average coordinates of the centroids








#### Corners detection



- Select multiple thresholds around the optimal one
- Compute the points corresponding to the minimum and maximum values of x in the black cluster
- Compute an average on the y values if more than one minimum/maximum is found on the same vertical axis








## Gaze recognition



Finally, the direction is assigned accordingly to the following criteria:

- If the distance from the iris and the left corner is less than 45% of the distance between the two corners, the value RIGHT is assigned.
- If the distance from the iris and the left corner is more than 55% of the distance between the two corners, the value LEFT is assigned.
- Otherwise, STRAIGHT is assigned.




# Results









RIGHT STRAIGHT LEFT

9




# Results



**RIGHT** 






# Results










STRAIGHT STRAIGHT RIGHT





# Thank you for your attention